











RATH I 7114A-M1

Designed by GIORMANI



RATH I 7114A-M1

Designed by GIORMANI



Remark:

E1-Electrical Switch with USB電按制連USB插頭

E2-Head+Seat (2) function 頭+座 (2) 功能

R2-2 Motions Recliner Remote Control 電遙控

HM-With Electrical Head Mechanism & Button switch 電動頭功能

RM-Reclining Mechanism 彈較功能(腳踏板、座位、屏同步移動)

功能/開關搭配表

功能 \ 開關	E1	E2	R2
RM+HM		✓	✓
HM	✓		

此為簡易圖僅供參考基本資料之用。

梳化產品屬軟性產品，請預算每件產品

規格會有公差為+/-5 厘米之內。

詳情必須查詢店員。（單位：cm）

The information is used for reference only.

The actual size of each piece of the product

should be subject to the discrepancies of +/-5cm.

Please check with our salespersons for further details.

26/3/2025